




PROPER HARNESS FIT

PLEASE NOTE: THESE INSTRUCTIONS ARE SUGGESTIONS FOR CHECKING HARNESS FIT ONLY. IF YOU HAVE SPECIFIC QUESTIONS, OR ARE NOT FAMILIAR WITH FITTING A HARNESS TO YOUR DOG, PLEASE SEE YOUR TAIGA DEALER

How do I properly fit the collared-neck H-back?



IMPORTANT: Check fit while harness tug is clipped to a load and dog is standing in a pulling posture-with head down and tension on the harness.

1. **Check the ribcage:** Feel for the dog's last rib with your fingertips. The cross-strap should lie just beyond the location of the last rib. If the strap is too far back, the dog can roll out the side of the harness when the dog is lying down.
2. **Check the length:** Feel for the base of the dog's tail with your fingertips. The joints where the top and bottom straps of the harness come together should be located on the sides of the hips adjacent to the base of the dog's tail. The end of the harness and tug extend beyond the base of the tail.
3. **Check the neck opening:** Pull all of the dog's excess neck skin and hair clear of the harness neck. Reach into the front of the neck opening with your finger and feel for the top of the sternum (bony projection). The sternum should be located just under the top of the breastplate.

Tip: To easily remove the collared neck harness, roll the neck opening inside-out before you pull it over the dog's head.